

LONGITUDINAL DYNAMICS



Frank Tecker
CERN, BE-OP



Basics of Accelerator Physics and Technology
ESI, Archamps, 7-11 October 2019

Scope and Summary of the 2 lectures:

The goal of an accelerator is to provide a **stable particle beam**.

The particles nevertheless perform **transverse betatron oscillations**.

We will see that they also perform **oscillations** in the **longitudinal** plane and in **energy**.

We will look at the stability of these oscillations, and their dynamics.


- Acceleration methods
- Accelerating structures
- Linac: Phase Stability + Energy-Phase oscillations
- Circular accelerators: Cyclotron / Synchrotron
- Stability in a Synchrotron
- Longitudinal Phase Space Motion
- Bunch and Bucket
- Injection Matching + Filamentation
- RF manipulations in the PS

More related lectures:

- Linacs
- RF Systems

- Alessandra Lombardi
- myself

The CERN Accelerator Complex



- Linear accelerators scale in size and cost(!) ~linearly with the energy.
 - Circular accelerators can each turn reuse
 - the accelerating system
 - the vacuum chamber 4
 - the bending/focusing magnets
 - beam instrumentation, ...
- > economic solution to reach higher particle energies
 But each accelerator has a limited energy range.

Particle types and acceleration

The accelerating system will depend upon the **evolution** of the **particle velocity**:

- **electrons** reach a **constant velocity** (~speed of light) at relatively low energy
- **heavy particles** reach a constant velocity only at very high energy
 - > we need different types of resonators, optimized for different velocities
 - > the **revolution frequency will vary**, so the **RF frequency will be changing**
 - > magnetic field needs to follow the momentum increase

Particle rest mass m_0 :

electron 0.511 MeV

proton 938 MeV

^{239}U ~220000 MeV

Total Energy: $E = \gamma m_0 c^2$


Relativistic

gamma factor:

$$\gamma = \frac{E}{E_0} = \frac{m}{m_0} = \frac{1}{\sqrt{1 - \beta^2}}$$

Momentum:

$$p = mv = \frac{E}{c^2} \beta c = \beta \frac{E}{c} = \beta \gamma m_0 c$$



Revolution frequency variation

The **revolution and RF frequency** will be **changing** during acceleration
Much **more important for lower energies** (values are kinetic energy - protons).

PS Booster: 50 MeV ($\beta = 0.314$) \rightarrow 1.4 GeV ($\beta = 0.915$)
(pre LS2) 602 kHz \rightarrow 1746 kHz \Rightarrow **190% frequency increase**
(post LS2): 160 MeV ($\beta = 0.520$) \rightarrow 2 GeV ($\beta = 0.948$) \Rightarrow **95% increase**

PS: 1.4 GeV ($\beta = 0.915$) \rightarrow 25.4 GeV ($\beta = 0.9994$)
437 kHz \rightarrow 477 kHz \Rightarrow **9% increase**
(post LS2): 2 GeV ($\beta = 0.948$) \rightarrow 25.4 GeV ($\beta = 0.9994$) \Rightarrow **5% increase**

SPS: 25.4 GeV \rightarrow 450 GeV ($\beta = 0.999998$)
 \Rightarrow **0.06% frequency increase**

LHC: 450 GeV \rightarrow 7 TeV ($\beta = 0.9999999991$)
 \Rightarrow only **2 10^{-6} increase**

RF system needs more flexibility in **lower energy** accelerators.

Acceleration: May the force be with you



To accelerate, we need a **force in the direction of motion!**

Newton-Lorentz Force on a charged particle with charge e (electron, proton)

$$\vec{F} = \frac{d\vec{p}}{dt} = e \left(\vec{E} + \vec{v} \times \vec{B} \right)$$

2nd term always perpendicular to motion \Rightarrow **no acceleration**

Hence, it is necessary to have an **electric field E** (preferably) **along the direction of the initial momentum (z)**, which changes the momentum of the particle.

$$\frac{dp}{dt} = eE_z$$

The 2nd term - larger at high velocities - is used for:

- **BENDING**: generated by a magnetic field perpendicular to the plane of the particle trajectory. The bending radius ρ obeys to the relation :

$$\frac{p}{e} = B\rho$$

in practical units: $B \rho [\text{Tm}] \approx \frac{p [\text{GeV}/c]}{0.3}$

- **FOCUSING**: the bending effect is used to bring the particles trajectory closer to the axis, hence to increase the beam density.

Energy Gain

The acceleration increases the **momentum**, providing **kinetic energy** to the charged particles.

In relativistic dynamics, **total energy** E and **momentum** p are **linked by**

$$E^2 = E_0^2 + p^2 c^2$$

$$(E = E_0 + W)$$

W kinetic energy

E_0 rest energy

Hence: $dE = v dp$

$$(2E dE = 2c^2 p dp \Leftrightarrow dE = c^2 mv / E dp = v dp)$$

The rate of **energy gain per unit length** of acceleration (along z) is then:

$$\frac{dE}{dz} = v \frac{dp}{dz} = \frac{dp}{dt} = eE_z$$

and the kinetic **energy gained** from the field along the z path is:

$$dW = dE = eE_z dz \quad \rightarrow \quad W = e \int E_z dz = eV$$

where V is just a potential.

Unit of Energy

Today's accelerators and future projects work/aim at the **TeV energy** range.

LHC: 7 TeV -> 14 TeV

CLIC: 3 TeV

HE/VHE-LHC: 33/100 TeV

In fact, this energy unit comes from acceleration:

1 eV (electron Volt) is the energy that 1 elementary charge e (like one electron or proton) gains when it is accelerated in a potential (voltage) difference of 1 Volt.

Basic Unit: eV (electron Volt)


keV = 1000 eV = 10^3 eV

MeV = 10^6 eV


GeV = 10^9 eV

TeV = 10^{12} eV

LHC = ~450 Million km of batteries!!!
3x distance Earth-Sun



Electrostatic Acceleration




Electrostatic Field:

Force:
$$\vec{F} = \frac{d\vec{p}}{dt} = e \vec{E}$$

Energy gain:
$$W = e \Delta V$$


used for first stage of acceleration:
particle sources, electron guns,
x-ray tubes

Limitation: **insulation problems**
maximum high voltage (~ 10 MV)



Van-de-Graaf generator at MIT

Radio-Frequency (RF) Acceleration



G.Ising

Electrostatic acceleration limited by insulation possibilities => use **time-varying** fields

1924: Ising suggests drift-tubes with time-varying fields

1928: Widerøe builds first demonstration linac



R.Widerøe



Prinzip einer Methode zur Herstellung von Kanalstrahlen hoher Voltzahl.

Von

GUSTAF ISING.


Mit 2 Figuren im Texte.

Mitgeteilt am 12. März 1924 durch C. W. OSEEN und M. SIRGDAHN.



P.Lebrun

Radio-Frequency (RF) Acceleration




Widerøe-type structure

Animation: http://www.sciences.univ-nantes.fr/sites/genevieve_tulloue/Meca/Charges/linac.html

Cylindrical electrodes (**drift tubes**) separated by gaps and fed by a **RF generator**, as shown above, lead to an alternating electric field polarity


Synchronism condition $\longrightarrow L = v T/2$ $v = \text{particle velocity}$
 $T = \text{RF period}$

Consequence: We can **only** accelerate **bunched beam**!



Similar for standing wave cavity as shown (with $v \approx c$)

RF acceleration: Alvarez Structure




Synchronism condition ($g \ll L$)




$$L = v_s T_{RF} = \beta_s \lambda_{RF}$$

$$\omega_{RF} = 2\pi f_{RF} = 2\pi \frac{v_s}{L}$$



Resonant RF Cavities


- Considering RF acceleration, it is obvious that when particles get high velocities the drift spaces get longer and one loses on the efficiency.
=> The solution consists of using a **higher operating frequency**.
- The **power lost** by radiation, due to circulating currents on the electrodes, is **proportional to the RF frequency**.
=> The solution consists of **enclosing the system in a cavity** which resonant frequency matches the RF generator frequency.




- The electromagnetic power is now constrained in the resonant volume
- Each such cavity can be independently powered from the RF generator
- Note however that joule losses will occur in the cavity walls (unless made of superconducting materials)

Some RF Cavity Examples



$L = vT/2$ (π mode)



$L = vT$ (2π mode)





Single Gap More in RF Systems IP



Common Phase Conventions

1. For **circular accelerators**, the origin of time is taken at the **zero crossing** of the RF voltage with positive slope
2. For **linear accelerators**, the origin of time is taken at the positive **crest** of the RF voltage

Time $t = 0$ chosen such that:




3. I will stick to **convention 1** in the following to avoid confusion

Principle of Phase Stability (Linac)

Let's consider a succession of accelerating gaps, operating in the 2π mode, for which the synchronism condition is fulfilled for a phase Φ_s .



$eV_s = e\hat{V} \sin \Phi_s$ is the energy gain in one gap for the particle to reach the next gap with the same RF phase: P_1, P_2, \dots are fixed points.

For a 2π mode, the electric field is the same in all gaps at any given time.



If an **energy increase** is transferred into a **velocity increase** \Rightarrow
 M_1 & N_1 will move towards **P_1** \Rightarrow **stable**
 M_2 & N_2 will go away from **P_2** \Rightarrow **unstable**
 (Highly relativistic particles have no significant velocity change)

A Consequence of Phase Stability



The divergence of the field is zero according to Maxwell :

$$\nabla \vec{E} = 0 \Rightarrow \frac{\partial E_x}{\partial x} + \frac{\partial E_z}{\partial z} = 0 \Rightarrow \frac{\partial E_x}{\partial x} = -\frac{\partial E_z}{\partial z}$$

Transverse fields

- **focusing** at the **entrance** and
- **defocusing** at the **exit** of the cavity.

Electrostatic case: Energy gain inside the cavity leads to focusing

RF case: **Field increases during passage** \Rightarrow **transverse defocusing!**

External focusing (solenoid, quadrupole) is then necessary

Energy-phase Oscillations (Small Amplitude) (1)

- Rate of **energy gain** for the **synchronous particle**:

$$\frac{dE_s}{dz} = \frac{dp_s}{dt} = eE_0 \sin \phi_s$$

- Use **reduced variables** with respect to **synchronous particle**

$$w = W - W_s = E - E_s \quad \varphi = \phi - \phi_s$$

Energy gain: $\frac{dw}{dz} = eE_0 [\sin(\phi_s + \varphi) - \sin \phi_s] \approx eE_0 \cos \phi_s \cdot \varphi \quad (\text{small } \varphi)$

- Rate of **phase change** with respect to the synchronous one:

$$\frac{d\varphi}{dz} = \omega_{RF} \left(\frac{dt}{dz} - \left(\frac{dt}{dz} \right)_s \right) = \omega_{RF} \left(\frac{1}{v} - \frac{1}{v_s} \right) \approx -\frac{\omega_{RF}}{v_s^2} (v - v_s)$$

Leads finally to: $\frac{d\varphi}{dz} = -\frac{\omega_{RF}}{m_0 v_s^3 \gamma_s^3} w$

Energy-phase Oscillations (Small Amplitude) (2)

Combining the two 1st order equations into a 2nd order equation gives the equation of a **harmonic oscillator**:

$$\frac{d^2 \phi}{dz^2} + \Omega_s^2 \phi = 0$$

with

$$\Omega_s^2 = \frac{eE_0 \omega_{RF} \cos \phi_s}{m_0 v_s^3 \gamma_s^3}$$

Slower for higher energy!

Stable harmonic oscillations imply:

$$\Omega_s^2 > 0 \quad \text{and real}$$

hence: $\cos \phi_s > 0$


And since acceleration also means:

$$\sin \phi_s > 0$$

You finally get the result for the **stable phase range**:

$$0 < \phi_s < \frac{\pi}{2}$$

Positive rising RF slope!



Summary up to here...

- **Acceleration by electric fields**, static fields limited
=> time-varying fields
 - **Synchronous condition** needs to be fulfilled for acceleration
 - Particles perform **oscillation** around synchronous phase
 - Stable acceleration on the rising slope in a linac.
-
- Electrons are quickly relativistic, speed does not change
 - Protons and ions need changing structure geometry and certain RF frequency range

Circular accelerators

Betatron

Cyclotron

Synchrotron

Acceleration by Induction: The Betatron

A **ramping magnetic field**



- **Guides particles** on a circular trajectory and
- Creates a tangential electric field that **accelerates** the particles

Limited by saturation in iron (~ 300 MeV e^-)

Used in industry and medicine, as they are compact accelerators for electrons



Donald Kerst with the first betatron, invented at the University of Illinois in 1940




Circular accelerators: Cyclotron



Courtesy: EdukiteLearning, <https://youtu.be/cNnNM2ZqIsc>


Circular accelerators: Cyclotron



Synchronism condition

$$\omega_s = \omega_{RF}$$

$$2\pi \rho = v_s T_{RF}$$



Cyclotron frequency

$$\omega = \frac{q B}{m_0 \gamma}$$

1. γ increases with the energy
 \Rightarrow no exact synchronism
2. if $v \ll c \Rightarrow \gamma \cong 1$

Cyclotron Animation

Animation: http://www.sciences.univ-nantes.fr/sites/genevieve_tulloue/Meca/Charges/cyclotron.html

Cyclotron / Synchrocyclotron



TRIUMF 520 MeV cyclotron Vancouver - Canada



CERN 600 MeV synchrocyclotron

Synchrocyclotron: Same as cyclotron, except a modulation of ω_{RF}

B = constant

$\gamma \omega_{RF}$ = constant

ω_{RF} decreases with time


The condition:

$$\omega_s(t) = \omega_{RF}(t) = \frac{q B}{m_0 \gamma(t)}$$

Allows to go beyond the non-relativistic energies

Empty Slide - Wait for the talk

Circular accelerators: The Synchrotron



1. **Constant orbit** during acceleration
2. To keep particles on the closed orbit, **B should increase** with time
3. **ω and ω_{RF} increase** with energy

RF frequency can be multiple of revolution frequency

$$\omega_{RF} = h\omega$$

Synchronism condition \rightarrow



$$T_s = h T_{RF}$$

$$\frac{2\pi R}{v_s} = h T_{RF}$$

h integer,
harmonic number:
 number of RF cycles per revolution


h is the **maximum number of bunches** in the synchrotron.
 Normally less bunches due to gaps for kickers, collision constraints,...

Circular accelerators: The Synchrotron




Examples of different
proton and electron
synchrotrons at CERN

+ LHC (of course!)



The Synchrotron

The **synchrotron** is a synchronous accelerator since there is a **synchronous RF phase** for which the energy gain **fits** the **increase of the magnetic field** at each turn. That implies the following operating conditions:



$$e\hat{V} \sin \phi \longrightarrow \text{Energy gain per turn}$$

$$\phi = \phi_s = cte \longrightarrow \text{Synchronous particle}$$

$$\omega_{RF} = h\omega \longrightarrow \text{RF synchronism (h - harmonic number)}$$


$$\rho = cte \quad R = cte \longrightarrow \text{Constant orbit}$$

$$B\rho = P/e \Rightarrow B \longrightarrow \text{Variable magnetic field}$$

If $v \approx c$, ω hence ω_{RF} remain constant (ultra-relativistic e^-)

The Synchrotron - LHC Operation Cycle

The magnetic **field** (dipole current) is **increased during** the **acceleration**.



L.Bottura

The Synchrotron - Energy ramping

Energy ramping by increasing the B field (frequency has to follow ν):


$$p = eB\rho \quad \rho \text{ const.} \Rightarrow \frac{dp}{dt} = e\rho \dot{B} \Rightarrow (\Delta p)_{turn} = e\rho \dot{B} T_r = \frac{2\pi e\rho R\dot{B}}{\nu}$$

With

$$E^2 = E_0^2 + p^2 c^2 \Rightarrow \Delta E = \nu \Delta p \quad (\Delta E)_{turn} = (\Delta W)_s = 2\pi e\rho R\dot{B} = e\hat{V} \sin\phi_s$$


Synchronous phase ϕ_s changes during energy ramping

$$\sin\phi_s = 2\pi\rho R \frac{\dot{B}}{\hat{V}_{RF}}$$



$$\phi_s = \arcsin\left(2\pi\rho R \frac{\dot{B}}{\hat{V}_{RF}}\right)$$

- The **synchronous phase** depends on
 - the **change of the magnetic field**
 - and the RF voltage



The Synchrotron - Frequency change

During the energy ramping, **the RF frequency increases** to follow the increase of the revolution frequency :

$$\omega = \frac{\omega_{RF}}{h} = \omega(B, R_s)$$

Hence:
$$\frac{f_{RF}(t)}{h} = \frac{v(t)}{2\pi R_s} = \frac{1}{2\pi} \frac{ec^2}{E_s(t)} \frac{\rho}{R_s} B(t) \quad \left(\text{using } p(t) = eB(t)\rho, \quad E = mc^2 \right)$$


Since $E^2 = (m_0c^2)^2 + p^2c^2$ the RF frequency must follow the variation of the B field with the law

$$\frac{f_{RF}(t)}{h} = \frac{c}{2\pi R_s} \left\{ \frac{B(t)^2}{(m_0c^2 / ec\rho)^2 + B(t)^2} \right\}^{1/2}$$

RF frequency program during acceleration determined by B-field !

Example: PS - Field / Frequency change

During the energy ramping, the **B-field** and the **revolution frequency** increase



Overtaking in a roundabout

Finally a real-life problem: what is the **fastest way through a roundabout?**

Most CERN people encounter this near the French entrance to CERN.




Empty Slide - Wait for the talk

Empty Slide - Wait for the talk

Empty Slide - Wait for the talk

Empty Slide - Wait for the talk

Overtaking in a Synchrotron



A particle slightly shifted in momentum will have a

- dispersion orbit and a **different orbit length** (higher momentum => less bent in magnet)
- a **different velocity**.

As a result of both effects the revolution frequency changes with a "slip factor η ":

$$\eta = \frac{df_r / f_r}{dp / p} \Rightarrow \eta = \frac{p}{f_r} \frac{df_r}{dp}$$

Note: you also find η defined with a minus sign!

p =particle momentum

R =synchrotron physical radius

f_r =revolution frequency

Effect from orbit defined by **Momentum compaction factor**:

$$\alpha_c = \frac{dL/L}{dp/p}$$

Property of the **transverse beam optics**:

(derivation in Appendix)

$$\alpha_c = \frac{1}{L} \int_C \frac{D_x(s)}{\rho(s)} ds_0$$

Dispersion Effects - Revolution Frequency

The **two effects** of the **orbit length** and the particle **velocity** change the revolution frequency as:

$$f_r = \frac{\beta c}{2\pi R} \quad \Rightarrow \quad \frac{df_r}{f_r} = \frac{d\beta}{\beta} - \frac{dR}{R} \stackrel{\substack{\text{definition of momentum} \\ \text{compaction factor}}}{=} \frac{d\beta}{\beta} - \alpha_c \frac{dp}{p}$$

$$\frac{df_r}{f_r} = \left(\frac{1}{\gamma^2} - \alpha_c \right) \frac{dp}{p}$$


$$p = mv = \beta\gamma \frac{E_0}{c} \quad \Rightarrow \quad \frac{dp}{p} = \frac{d\beta}{\beta} + \frac{d(1-\beta^2)^{-1/2}}{(1-\beta^2)^{-1/2}} = \underbrace{(1-\beta^2)^{-1}}_{\gamma^2} \frac{d\beta}{\beta}$$

Slip factor: $\eta = \frac{1}{\gamma^2} - \alpha_c$ or $\eta = \frac{1}{\gamma^2} - \frac{1}{\gamma_t^2}$ with $\gamma_t = \frac{1}{\sqrt{\alpha_c}}$

At **transition energy**, $\eta = 0$, the velocity change and the path length change with momentum compensate each other. So the revolution frequency there is independent from the momentum deviation.

Phase Stability in a Synchrotron

- From the definition of η it is clear that an **increase in momentum** gives
- **below transition** ($\eta > 0$) a **higher revolution frequency** (increase in velocity dominates) while
 - **above transition** ($\eta < 0$) a **lower revolution frequency** ($v \approx c$ and longer path) where the momentum compaction (generally > 0) dominates.




Crossing Transition

At **transition**, the velocity change and the path length change with momentum compensate each other. So the revolution frequency there is independent from the momentum deviation.

Crossing transition during acceleration makes the previous stable synchronous phase unstable. The RF system needs to make a rapid change of the RF phase, a '**phase jump**'.

$$\alpha_c \sim \frac{1}{Q_x^2} \quad \gamma_t = \frac{1}{\sqrt{\alpha_c}} \sim Q_x$$



In the PS: γ_t is at ~ 6 GeV

In the SPS: $\gamma_t = 22.8$, injection at $\gamma = 27.7$

=> no transition crossing!

In the LHC: γ_t is at ~ 55 GeV, also far below injection energy


Transition crossing not needed in leptons machines, why?

Dynamics: Synchrotron oscillations

Simple case (no accel.): $B = \text{const.}$, below transition $\gamma < \gamma_t$


The phase of the synchronous particle must therefore be $\phi_0 = 0$.

- Φ_1
- The particle **B** is accelerated
 - Below transition, an energy increase means an increase in revolution frequency
 - The particle arrives earlier - tends toward ϕ_0



- ϕ_2
- The particle is decelerated
 - decrease in energy - decrease in revolution frequency
 - The particle arrives later - tends toward ϕ_0

Synchrotron oscillations




Particle **B** performs **Synchrotron Oscillations** around synchronous particle **A**.

The amplitude depends on the initial phase and energy.

The **oscillation frequency** is much **slower than** in the **transverse** plane. It takes a large number of revolutions for one complete oscillation. The restoring electric force is smaller than the magnetic force.

- proton synchrotrons of the order of 1000 turns
- electron storage rings of the order of ~10 turns

The Potential Well




Cavity voltage


Potential well

Longitudinal phase space

The **energy - phase oscillations** can be drawn in **phase space**.
Similar to transverse, but here it's **TIME and ENERGY!**



The particle trajectory in the phase space ($\Delta p/p, \phi$) describes its longitudinal motion.




Emittance: phase space area including all the particles

NB: if the emittance contour correspond to a possible orbit in phase space, its shape does not change with time (matched beam)


Longitudinal Phase Space Motion

Particle **B** oscillates around particle **A** in a synchrotron oscillation.


Plotting this motion in longitudinal phase space (time, energy) gives:



Synchrotron oscillations - No acceleration




Phase space picture




Synchrotron motion in phase space

ΔE - ϕ phase space of a **stationary bucket**
(when there is **no acceleration**)



Dynamics of a particle
Non-linear, conservative
oscillator → e.g. pendulum


Particle inside
the separatrix:



Particle at the
unstable fix-point




Particle outside
the separatrix:



Bucket area: area enclosed
by the separatrix
**The area covered by particles is
the longitudinal emittance**

(Stationary) Bunch & Bucket

The **bunches** of the beam **fill** usually **a part of** the **bucket** area.



Bucket area = longitudinal Acceptance [eVs]

Bunch area = longitudinal beam emittance = $4\pi \sigma_E \sigma_t$ [eVs]


Attention: Different definitions are used!

Synchrotron motion in phase space

The restoring force is **non-linear**.

⇒ speed of motion depends on position in phase-space


(here shown for a stationary bucket)




Synchrotron oscillations (with acceleration)

Case with acceleration B increasing

$$\gamma < \gamma_t$$




Phase space picture



$$\phi_s < \phi < \pi - \phi_s$$

The symmetry of the case $B = \text{const.}$ is lost

RF Acceptance versus Synchronous Phase



The **areas of stable motion** (closed trajectories) are called "**BUCKET**". The number of circulating buckets is equal to " h ".

The phase extension of the **bucket is maximum** for $\phi_s = 180^\circ$ (or 0°) which means **no acceleration**.

During **acceleration**, the buckets get **smaller**, both in length and **energy acceptance**.

=> **Injection** preferably **without acceleration**.

Longitudinal Dynamics in Synchrotrons

Now we will look more quantitatively at the "synchrotron motion".

The RF acceleration process clearly emphasizes two coupled variables, the **energy** gained by the particle and the **RF phase** experienced by the same particle.

Since there is a **well defined synchronous particle** which has always the same **phase** ϕ_s , and the nominal **energy** E_s , it is sufficient to follow other particles with respect to that particle.

So let's introduce the following **reduced variables**:

revolution frequency : $\Delta f_r = f_r - f_{rs}$

particle RF phase : $\Delta\phi = \phi - \phi_s$

particle momentum : $\Delta p = p - p_s$

particle energy : $\Delta E = E - E_s$

azimuth angle : $\Delta\theta = \theta - \theta_s$

Look at **difference**
from **synchronous**
particle

Equations of Longitudinal Motion

In these reduced variables, the **equations of motion** are (see Appendix):

$$\frac{\Delta E}{\omega_{rs}} = -\frac{p_s R_s}{h \eta \omega_{rs}} \frac{d(\Delta \phi)}{dt} = -\frac{p_s R_s}{h \eta \omega_{rs}} \dot{\phi}$$

$$2\pi \frac{d}{dt} \left(\frac{\Delta E}{\omega_{rs}} \right) = e \hat{V} (\sin \phi - \sin \phi_s)$$

deriving and combining

$$\frac{d}{dt} \left[\frac{R_s p_s}{h \eta \omega_{rs}} \frac{d\phi}{dt} \right] + \frac{e \hat{V}}{2\pi} (\sin \phi - \sin \phi_s) = 0$$

This second order equation is non linear. Moreover the parameters within the bracket are in general slowly varying with time.

We will simplify in the following...

Small Amplitude Oscillations

Let's assume constant parameters R_s , p_s , ω_s and η :

$$\ddot{\phi} + \frac{\Omega_s^2}{\cos\phi_s} (\sin\phi - \sin\phi_s) = 0$$

with

$$\Omega_s^2 = \frac{h\eta\omega_{rs}e\hat{V}\cos\phi_s}{2\pi R_s p_s}$$

Consider now **small phase deviations** from the reference particle:

$$\sin\phi - \sin\phi_s = \sin(\phi_s + \Delta\phi) - \sin\phi_s \cong \cos\phi_s \Delta\phi \quad (\text{for small } \Delta\phi)$$

and the corresponding linearized motion reduces to a **harmonic oscillation**:

$$\ddot{\phi} + \Omega_s^2 \Delta\phi = 0 \quad \text{where } \Omega_s \text{ is the } \text{synchrotron angular frequency}.$$

The **synchrotron tune** ν_s is the number of synchrotron oscillations per revolution:

$$\nu_s = \Omega_s / \omega_s$$

Typical values are $\ll 1$, as it takes several 10 - 1000 turns per oscillation.

- proton synchrotrons of the order 10^{-3}
- electron storage rings of the order 10^{-1}

Stability condition for ϕ_s

$$\Omega_s^2 = \frac{e\hat{V}_{RF}\eta h\omega_s}{2\pi R_s p_s} \cos \phi_s$$

$$\Leftrightarrow \Omega_s^2 = \omega_s^2 \frac{e\hat{V}_{RF}\eta h}{2\pi\beta^2 E} \cos \phi_s \quad \text{with } Rp = \frac{\beta^2 E}{\omega}$$


Stability is obtained when Ω_s is real and so Ω_s^2 positive:

$$\Omega_s^2 > 0$$

\Leftrightarrow

$$\eta \cos \phi_s > 0$$

Stable in the region if




Energy Acceptance

From the equation of the separatrix, we can calculate (see appendix) the **acceptance in energy**:

$$\left(\frac{\Delta E}{E_s}\right)_{\max} = \pm \beta \sqrt{\frac{e\hat{V}}{\pi h \eta E_s} G(\phi_s)}$$

$$G(\phi_s) = [2\cos\phi_s + (2\phi_s - \pi)\sin\phi_s]$$




This “**RF acceptance**” depends strongly on ϕ_s and plays an important role for the capture at injection, and the stored beam lifetime.

It's **largest** for $\phi_s=0$ and $\phi_s=\pi$ (**no acceleration**, depending on η).

It becomes smaller during acceleration, when ϕ_s is changing

Need a **higher RF voltage** for **higher acceptance** => need more \$€ ☹

RF Acceptance versus Synchronous Phase



The **areas of stable motion** (closed trajectories) are called "**BUCKET**". The number of circulating buckets is equal to " h ".



The phase extension of the **bucket is maximum** for $\phi_s = 180^\circ$ (or 0°) which means **no acceleration**.

During **acceleration**, the buckets get **smaller**, both in length and **energy acceptance**.

=> **Injection** preferably **without acceleration**.

Injection: Bunch-to-bucket transfer

- Bunch from sending accelerator into the bucket of receiving




Advantages:


- Particles always subject to longitudinal focusing
- No need for RF capture of de-bunched beam in receiving accelerator
- No particles at unstable fixed point
- Time structure of beam preserved during transfer

Effect of a Mismatch


Injected bunch: short length and large energy spread
 after 1/4 synchrotron period: longer bunch with a smaller energy spread.




For **larger amplitudes**, the angular phase space motion is slower (1/8 period shown below) => can lead to **filamentation** and **emittance growth**



restoring force is non-linear



stationary bucket




accelerating bucket

W.Pirkl

Effect of a Mismatch (2)


- Long. emittance is only preserved for **correct RF voltage**

Matched case



→ Bunch is fine, longitudinal emittance remains constant

Longitudinal mismatch




→ Dilution of bunch results in increase of long. emittance


Effect of a Mismatch (3)

Evolution of an injected beam for the first 100 turns.

For a mismatched transfer, the emittance increases (right).



matched beam




mismatched beam - phase error


Bunch Rotation

Phase space motion can be used to make short bunches.



Start with a long bunch and extract or recapture when it's short.





initial beam



Capture of a Debunched Beam with Fast Turn-On




Capture of a Debunched Beam with Adiabatic Turn-On



Generating a 25ns Bunch Train in the PS

- **Longitudinal bunch splitting (basic principle)**
 - Reduce voltage on principal RF harmonic and simultaneously rise voltage on multiple harmonics (adiabatically with correct phase, etc.)

PS ejection:
72 bunches
in 1 turn




72 bunches
on $h=84$

*Quadruple splitting
at 25 GeV*

40 MHz fixed
RF = 40.0 MHz
 1.1×10^{11} ppb
&
20 MHz fixed
RF = 20.0 MHz
 2.2×10^{11} ppb

Acceleration
to 25 GeV




18 bunches
on $h=21$

*Triple splitting
at 1.4 GeV*

10 MHz system
RF = 9.18 MHz
 4.4×10^{11} ppb

PS injection:
4+2 bunches
in 2 batches



6 bunches
on $h=7$

Empty
bucket


10 MHz system
RF = 3.06 MHz
 13.2×10^{11} ppb

R. Garoby

Use double splitting at 25 GeV to generate 50ns bunch trains instead


Production of the LHC 25 ns beam

1. Inject four bunches ~ 180 ns, 1.3 eVs




Wait 1.2 s for second injection

2. Inject two bunches



3. Triple split after second injection




~ 0.7 eVs


4. Accelerate from 1.4 GeV (E_{kin}) to 26 GeV

Production of the LHC 25 ns beam


5. During acceleration: longitudinal emittance blow-up: **0.7 – 1.3 eVs**



6. Double split ($h21 \rightarrow h42$)






7. Double split ($h42 \rightarrow h84$) ~ 0.35 eVs, 4 ns




10. Fine synchronization, bunch rotation \rightarrow Extraction!

The LHC25 (ns) cycle in the PS





→ Each bunch from the Booster divided by **12** → **6 × 3 × 2 × 2 = 72**

Triple splitting in the PS



Two times double splitting in the PS

Two times double splitting and bunch rotation:



- Bunch is divided twice using RF systems at $h = 21/42$ (10/20 MHz) and $h = 42/84$ (20/40 MHz)
- Rotation: first part $h84$ only + $h168$ (80 MHz) for final part

Summary

- Cyclotrons/Synchrocyclotrons for low energy
- **Synchrotrons** for high energies, constant orbit, rising field and frequency synchronously
- Particles with higher energy have a longer orbit (normally) but a higher velocity
 - at low energies (below transition) velocity increase dominates
 - at high energies (above transition) velocity almost constant
- Particles perform **oscillations around synchronous phase**
 - synchronous phase depending on acceleration
 - below or above transition
- **Bucket** is the stable region in phase space inside the **separatrix**
- **Bunch** is the area filled with beam
- **Matching** the shape of the bunch to the bucket is essential

Bibliography

- S.Y. Lee **Accelerator Physics**
(World Scientific, 2011)
- M. Conte, W.W. Mac Kay **An Introduction to the Physics of particle Accelerators**
(World Scientific, 1991)
- P. J. Bryant and K. Johnsen **The Principles of Circular Accelerators and Storage Rings**
(Cambridge University Press, 1993)
- D. A. Edwards, M. J. Syphers **An Introduction to the Physics of High Energy Accelerators**
(J. Wiley & sons, Inc, 1993)
- H. Wiedemann **Particle Accelerator Physics**
(Springer-Verlag, Berlin, 1993)
- M. Reiser **Theory and Design of Charged Particles Beams**
(J. Wiley & sons, 1994)
- A. Chao, M. Tigner **Handbook of Accelerator Physics and Engineering**
(World Scientific 1998)
- K. Wille **The Physics of Particle Accelerators: An Introduction**
(Oxford University Press, 2000)
- E.J.N. Wilson **An introduction to Particle Accelerators**
(Oxford University Press, 2001)



And CERN Accelerator Schools (CAS) Proceedings
In particular: CERN-2014-009
Advanced Accelerator Physics - CAS

Acknowledgements

I would like to thank everyone for the material that I have used.

In particular (hope I don't forget anyone):

- Joël Le Duff (from whom I inherited the course)
- Rende Steerenberg
- Gerald Dugan
- Heiko Damerau
- Werner Pirkl
- Genevieve Tulloue
- Mike Syphers
- Daniel Schulte
- Roberto Corsini
- Roland Garoby
- Luca Bottura
- Berkeley Lab
- Edukite Learning

Appendix

- Summary Relativity and Energy Gain
- Velocity, Energy, and Momentum
- Momentum compaction factor
- Synchrotron energy-phase oscillations
- Stability condition
- Separatrix stationary bucket
- Large amplitude oscillations
- Bunch matching into stationary bucket

Appendix: Relativity + Energy Gain

Newton-Lorentz Force $\vec{F} = \frac{d\vec{p}}{dt} = e \left(\vec{E} + \vec{v} \times \vec{B} \right)$ 2nd term always perpendicular to motion \Rightarrow no acceleration

Relativistic Dynamics

$$\beta = \frac{v}{c} = \sqrt{1 - \frac{1}{\gamma^2}} \quad \gamma = \frac{E}{E_0} = \frac{m}{m_0} = \frac{1}{\sqrt{1 - \beta^2}}$$

$$p = mv = \frac{E}{c^2} \beta c = \beta \frac{E}{c} = \beta \gamma m_0 c$$

$$E^2 = E_0^2 + p^2 c^2 \quad \longrightarrow \quad dE = v dp$$

$$\frac{dE}{dz} = v \frac{dp}{dz} = \frac{dp}{dt} = e E_z$$

$$dE = dW = e E_z dz \quad \rightarrow \quad W = e \int E_z dz$$

RF Acceleration

$$E_z = \hat{E}_z \sin \omega_{RF} t = \hat{E}_z \sin \phi(t)$$

$$\int \hat{E}_z dz = \hat{V}$$

$$W = e \hat{V} \sin \phi$$

(neglecting transit time factor)

The field will change during the passage of the particle through the cavity
 \Rightarrow effective energy gain is lower

Appendix: Velocity, Energy and Momentum

normalized velocity $\beta = \frac{v}{c} = \sqrt{1 - \frac{1}{\gamma^2}}$

=> electrons almost reach the speed of light very quickly (few MeV range)



total energy
rest energy

$$E = \gamma m_0 c^2$$

$$\gamma = \frac{E}{E_0} = \frac{m}{m_0} = \frac{1}{\sqrt{1 - \frac{v^2}{c^2}}} = \frac{1}{\sqrt{1 - \beta^2}}$$

Momentum $p = mv = \frac{E}{c^2} \beta c = \beta \frac{E}{c} = \beta \gamma m_0 c$

=> Magnetic field needs to follow the momentum increase




Appendix: Momentum Compaction Factor

$$\alpha_c = \frac{p}{L} \frac{dL}{dp}$$

$$ds_0 = \rho d\theta$$

$$ds = (\rho + x) d\theta$$



The elementary path difference from the two orbits is:

definition of dispersion D_x

$$\frac{dl}{ds_0} = \frac{ds - ds_0}{ds_0} = \frac{x}{\rho} \stackrel{\text{definition of } D_x}{=} \frac{D_x}{\rho} \frac{dp}{p}$$

leading to the total change in the circumference:

$$dL = \int_C dl = \int_C \frac{x}{\rho} ds_0 = \int_C \frac{D_x}{\rho} \frac{dp}{p} ds_0$$


$$\alpha_c = \frac{1}{L} \int_C \frac{D_x(s)}{\rho(s)} ds_0$$

With $\rho = \infty$ in straight sections we get:

$$\alpha_c = \frac{\langle D_x \rangle_m}{R}$$

$\langle \rangle_m$ means that the average is considered over the bending magnet only

Appendix: First Energy-Phase Equation



$$f_{RF} = h f_r \Rightarrow \Delta\phi = -h \Delta\theta \quad \text{with} \quad \theta = \int \omega dt$$

particle ahead arrives earlier
 \Rightarrow smaller RF phase

For a given particle with respect to the reference one:

$$\Delta\omega = \frac{d}{dt}(\Delta\theta) = -\frac{1}{h} \frac{d}{dt}(\Delta\phi) = -\frac{1}{h} \frac{d\phi}{dt}$$

Since:

$$\eta = \frac{p_s}{\omega_{rs}} \left(\frac{d\omega}{dp} \right)_s$$

and

$$E^2 = E_0^2 + p^2 c^2$$

$$\Delta E = v_s \Delta p = \omega_{rs} R_s \Delta p$$

one gets:

$$\frac{\Delta E}{\omega_{rs}} = -\frac{p_s R_s}{h \eta \omega_{rs}} \frac{d(\Delta\phi)}{dt} = -\frac{p_s R_s}{h \eta \omega_{rs}} \dot{\phi}$$

Appendix: Second Energy-Phase Equation

The rate of energy gained by a particle is: $\frac{dE}{dt} = e\hat{V} \sin\phi \frac{\omega_r}{2\pi}$

The rate of relative energy gain with respect to the reference particle is then:

$$2\pi \Delta \left(\frac{\dot{E}}{\omega_r} \right) = e\hat{V} (\sin\phi - \sin\phi_s)$$

Expanding the left-hand side to first order:

$$\Delta \left(\dot{E} T_r \right) \cong \dot{E} \Delta T_r + T_{rs} \Delta \dot{E} = \Delta E \dot{T}_r + T_{rs} \Delta \dot{E} = \frac{d}{dt} \left(T_{rs} \Delta E \right)$$


leads to the second energy-phase equation:

$$2\pi \frac{d}{dt} \left(\frac{\Delta E}{\omega_{rs}} \right) = e\hat{V} (\sin\phi - \sin\phi_s)$$

Appendix: Stability condition for ϕ_s

Stability is obtained when Ω_s is real and so Ω_s^2 positive:

$$\Omega_s^2 = \frac{e \hat{V}_{RF} \eta h \omega_s}{2\pi R_s p_s} \cos \phi_s \Rightarrow \Omega_s^2 > 0 \Leftrightarrow \eta \cos \phi_s > 0$$



Appendix: Stationary Bucket - Separatrix


This is the case $\sin\phi_s=0$ (no acceleration) which means $\phi_s=0$ or π . The equation of the separatrix for $\phi_s=\pi$ (above transition) becomes:

$$\frac{\dot{\phi}^2}{2} + \Omega_s^2 \cos\phi = \Omega_s^2$$

$$\frac{\dot{\phi}^2}{2} = 2\Omega_s^2 \sin^2\frac{\phi}{2}$$

Replacing the phase derivative by the (canonical) variable W :

$$W = \frac{\Delta E}{\omega_{rf}} = -\frac{p_s R_s}{h\eta\omega_{rf}} \dot{\phi}$$



with $C=2\pi R_s$

and introducing the expression for Ω_s leads to the following equation for the separatrix:

$$W = \pm \frac{C}{\pi h c} \sqrt{\frac{-e\hat{V} E_s}{2\pi h \eta}} \sin\frac{\phi}{2} = \pm W_{bk} \sin\frac{\phi}{2}$$

Stationary Bucket (2)

Setting $\phi=\pi$ in the previous equation gives the height of the bucket:

$$W_{bk} = \frac{C}{\pi h c} \sqrt{\frac{-e \hat{V} E_s}{2 \pi h \eta}}$$

This results in the **maximum energy acceptance**:

$$\Delta E_{\max} = \omega_{rf} W_{bk} = \beta_s \sqrt{2 \frac{-e \hat{V}_{RF} E_s}{\pi \eta h}}$$

The area of the bucket is: $A_{bk} = 2 \int_0^{2\pi} W d\phi$

Since: $\int_0^{2\pi} \sin \frac{\phi}{2} d\phi = 4$

one gets:

$$A_{bk} = 8 W_{bk} = 8 \frac{C}{\pi h c} \sqrt{\frac{-e \hat{V} E_s}{2 \pi h \eta}}$$



$$W_{bk} = \frac{A_{bk}}{8}$$

Appendix: Large Amplitude Oscillations

For larger phase (or energy) deviations from the reference the second order differential equation is non-linear:

$$\ddot{\phi} + \frac{\Omega_s^2}{\cos \phi_s} (\sin \phi - \sin \phi_s) = 0 \quad (\Omega_s \text{ as previously defined})$$

Multiplying by $\dot{\phi}$ and integrating gives an invariant of the motion:

$$\frac{\dot{\phi}^2}{2} - \frac{\Omega_s^2}{\cos \phi_s} (\cos \phi + \phi \sin \phi_s) = I$$

which for small amplitudes reduces to:


$$\frac{\dot{\phi}^2}{2} + \Omega_s^2 \frac{(\Delta\phi)^2}{2} = I' \quad (\text{the variable is } \Delta\phi, \text{ and } \phi_s \text{ is constant})$$

Similar equations exist for the second variable : $\Delta E \propto d\phi/dt$

Large Amplitude Oscillations (2)

When ϕ reaches $\pi - \phi_s$ the force goes to zero and beyond it becomes non restoring.

Hence $\pi - \phi_s$ is an extreme amplitude for a stable motion which in the phase space $(\frac{\dot{\phi}}{\Omega_s}, \Delta\phi)$ is shown as closed trajectories.



Equation of the **separatrix**:

$$\frac{\dot{\phi}^2}{2} - \frac{\Omega_s^2}{\cos \phi_s} (\cos \phi + \phi \sin \phi_s) = -\frac{\Omega_s^2}{\cos \phi_s} (\cos(\pi - \phi_s) + (\pi - \phi_s) \sin \phi_s)$$

Second value ϕ_m where the separatrix crosses the horizontal axis:

$$\cos \phi_m + \phi_m \sin \phi_s = \cos(\pi - \phi_s) + (\pi - \phi_s) \sin \phi_s$$

Energy Acceptance

From the equation of motion it is seen that $\dot{\phi}$ reaches an extreme when $\ddot{\phi} = 0$, hence corresponding to $\phi = \phi_s$.

Introducing this value into the equation of the separatrix gives:

$$\dot{\phi}_{\max}^2 = 2\Omega_s^2 \left\{ 2 + (2\phi_s - \pi) \tan \phi_s \right\}$$

That translates into an **acceptance in energy**:

$$\left(\frac{\Delta E}{E_s} \right)_{\max} = \pm \beta \sqrt{\frac{e\hat{V}}{\pi h \eta E_s} G(\phi_s)}$$

$$G(\phi_s) = [2 \cos \phi_s + (2\phi_s - \pi) \sin \phi_s]$$

This “**RF acceptance**” depends strongly on ϕ_s and plays an important role for the capture at injection, and the stored beam lifetime.


It's **largest** for $\phi_s=0$ and $\phi_s=\pi$ (**no acceleration**, depending on η).

Need a **higher RF voltage** for **higher acceptance**.

Bunch Matching into a Stationary Bucket

A particle trajectory inside the separatrix is described by the equation:

$$\frac{\dot{\phi}^2}{2} - \frac{\Omega_s^2}{\cos\phi_s} (\cos\phi + \phi \sin\phi_s) = I \quad \xrightarrow{\phi_s = \pi} \quad \frac{\dot{\phi}^2}{2} + \Omega_s^2 \cos\phi = I$$



The points where the trajectory crosses the axis are symmetric with respect to $\phi_s = \pi$

$$\frac{\dot{\phi}^2}{2} + \Omega_s^2 \cos\phi = \Omega_s^2 \cos\phi_m$$

$$\dot{\phi} = \pm \Omega_s \sqrt{2(\cos\phi_m - \cos\phi)}$$

$$W = \pm W_{bk} \sqrt{\cos^2 \frac{\varphi_m}{2} - \cos^2 \frac{\varphi}{2}}$$

$$\cos(\phi) = 2 \cos^2 \frac{\phi}{2} - 1$$

Bunch Matching into a Stationary Bucket (2)

Setting $\phi = \pi$ in the previous formula allows to calculate the bunch height:

$$W_b = W_{bk} \cos \frac{\phi_m}{2} = W_{bk} \sin \frac{\hat{\phi}}{2}$$

or:

$$W_b = \frac{A_{bk}}{8} \cos \frac{\phi_m}{2}$$

$$\longrightarrow \left(\frac{\Delta E}{E_s} \right)_b = \left(\frac{\Delta E}{E_s} \right)_{RF} \cos \frac{\phi_m}{2} = \left(\frac{\Delta E}{E_s} \right)_{RF} \sin \frac{\hat{\phi}}{2}$$

This formula shows that for a given bunch energy spread the proper matching of a **shorter bunch** (ϕ_m close to π , $\hat{\phi}$ small) will **require** a bigger RF acceptance, hence a **higher voltage**

For small oscillation amplitudes the equation of the ellipse reduces to:

$$W = \frac{A_{bk}}{16} \sqrt{\hat{\phi}^2 - (\Delta\phi)^2} \longrightarrow \left(\frac{16W}{A_{bk}\hat{\phi}} \right)^2 + \left(\frac{\Delta\phi}{\hat{\phi}} \right)^2 = 1$$

Ellipse area is called longitudinal emittance

$$A_b = \frac{\pi}{16} A_{bk} \hat{\phi}^2$$