
## Injection and extraction

- Kickers and septa
- Injection methods
  - Single-turn hadron injection
  - Injection errors, filamentation and blow-up
  - Multi-turn hadron injection
  - Charge-exchange H- injection
  - Lepton injection
- Extraction methods
  - Single-turn (fast) extraction
  - Non-resonant multi-turn extraction
  - Resonant multi-turn (slow) extraction

#### Brennan Goddard (presented by Wolfgang Bartmann) CERN

#### Injection, extraction and transfer

- An accelerator has limited dynamic range.
- Chain of stages needed to reach high energy
- Periodic re-filling of storage rings, like LHC




Beam transfer (into, out of, and between machines) is necessary.

LHC: SPS:	Large Hadron Collider Super Proton Synchrotron
AD:	Antiproton Decelerator
ISOLDE:	Isotope Separator Online Device
PSB:	Proton Synchrotron Booster
PS:	Proton Synchrotron
LINAC:	LINear Accelerator
LEIR:	Low Energy Ring
CNGS:	<b>CERN Neutrino to Gran Sasso</b>


## **Kicker** magnet

Pulsed magnet with very fast rise time (100ns – few  $\mu$ s)





## Magnetic septum



## **Electrostatic septum**


DC electrostatic device with very thin (~0.1mm) septum between zero field and high field region High voltage Hollow earth electrode Hollow earth electrode Septum wires electrode g E E=0Thin wire or foil (~0.1 mm) E = V / gTypically V = 200 kVE = 100 kV/cmHigh Voltage Electrode

#### Normalised phase space


• Transform real transverse coordinates *x*, *x*' by

$$\begin{bmatrix} \overline{\mathbf{X}} \\ \overline{\mathbf{X}'} \end{bmatrix} = \mathbf{N} \cdot \begin{bmatrix} x \\ x' \end{bmatrix} = \sqrt{\frac{1}{\beta_s}} \cdot \begin{bmatrix} 1 & 0 \\ \alpha_s & \beta_s \end{bmatrix} \cdot \begin{bmatrix} x \\ x' \end{bmatrix}$$
$$\overline{\mathbf{X}} = \sqrt{\frac{1}{\beta_s}} \cdot x$$
$$\overline{\mathbf{X}'} = \sqrt{\frac{1}{\beta_s}} \cdot \alpha_s x + \sqrt{\beta_s} x'$$

#### Normalised phase space



# Single-turn injection – same plane




- Septum deflects the beam onto the closed orbit at the centre of the kicker
- Kicker compensates for the remaining angle
- Septum and kicker either side of D quad to minimise kicker strength

# Single-turn injection


Normalised phase space at centre of idealised septum

Large deflection by septum



## Single-turn injection


 $\pi/2$  phase advance to kicker location





# Single-turn injection


Normalised phase space at centre of idealised kicker


Kicker deflection places beam on central orbit















• Betatron oscillations with respect to the Closed Orbit





- Non-linear effects (e.g. magnetic field multipoles) present which introduce amplitude dependent effects into particle motion.
- Over many turns, a phase-space oscillation is transformed into an emittance increase.
- So any residual transverse oscillation will lead to an emittance blowup through filamentation
  - "Transverse damper" systems used to damp injection oscillations bunch position measured by a pick-up, which is linked to a kicker



























# Damping of injection oscillations


- Residual transverse oscillations lead to an emittance blow-up through filamentation
- "Transverse damper" systems used to damp injection oscillations bunch position measured by a pick-up, which is linked to a kicker
- Damper measures offset of bunch on one turn, then kicks the bunch on a subsequent turn to reduce the oscillation amplitude



# **Optical Mismatch at Injection**


- Can also have an emittance blow-up through optical mismatch
- Individual particles oscillate with conserved CS invariant:

 $a_x = \gamma x^2 + 2\alpha xx' + \beta x'^2$ 




# **Optical Mismatch at Injection**

• Filamentation fills larger ellipse with same shape as matched ellipse



# Multi-turn injection


- For hadrons the beam density at injection can be limited either by space charge effects or by the injector capacity
- If we cannot increase charge density, we can sometimes fill the horizontal phase space to increase overall injected intensity.
  - Condition that the acceptance of receiving machine is larger than the delivered beam emittance





- No kicker
- Bump amplitude decreases and inject a new bunch at each turn
- Phase-space "painting"


Example: CERN PSB injection, fractional tune Qh = 0.25 Beam rotates  $\pi/2$  per turn in phase space


Turn 1










































In reality filamentation occurs to produce a quasi-uniform beam


#### Injection mismatch

For multiturn injection over *n* turns, injected beam ellipse is deliberately <u>mismatched</u> to circulating beam ellipse to reduce losses




- Multiturn injection is essential to accumulate high intensity
- Disadvantages inherent in using an injection septum
  - Width of several mm reduces aperture
  - Beam losses from circulating beam hitting septum
  - Limits number of injected turns to 10-20
- Charge-exchange injection provides elegant alternative
  - Possible to fully "deploy" Liouville's theorem, which says that emittance is conserved....
  - Convert H<sup>-</sup> to p<sup>+</sup> using a thin stripping foil, allowing injection <u>into the</u> <u>same phase space area</u>

Start of injection process




Injection chicane dipoles

End of injection process




- Paint uniform transverse phase space density by modifying closed orbit bump and steering injected beam
- Foil thickness calculated to double-strip most ions (>99%)
  - 50 MeV 50 μg.cm-2
  - 800 MeV 200 μg.cm-2 (~1μm of C!)
- Carbon foils generally used very fragile
- Injection chicane reduced or switched off after injection, to avoid excessive foil heating and beam blow up

## H- injection with laser stripping




#### H- injection - painting



## Lepton injection

- Single-turn injection can be used as for hadrons; however, lepton motion is <u>strongly damped</u> (different with respect to proton or ion injection).
  - Synchrotron radiation
- Can use transverse or longitudinal damping:
  - Transverse Betatron accumulation
  - Longitudinal Synchrotron accumulation


#### **Betatron lepton injection**



- Beam is injected with an angle with respect to the closed orbit
- Injected beam performs <u>damped</u> betatron oscillations about the closed orbit

### **Betatron lepton injection**


Injected bunch performs <u>damped</u> betatron oscillations



In LEP at 20 GeV, the damping time was about 6'000 turns (0.6 seconds)

## Synchrotron lepton injection


Inject an <u>off-momentum</u> beam



- Beam injected parallel to circulating beam, onto dispersion orbit of a particle having the same momentum offset ∆p/p.
- Injected beam makes damped synchrotron oscillations at Q<sub>s</sub> but does not perform betatron oscillations.


### Synchrotron lepton injection

Double batch injection possible....




Longitudinal damping time in LEP was ~ 3'000 turns (2 x faster than transverse)

## Synchrotron lepton injection in LEP



Optimized Horizontal First Turn Trajectory for Betatron Injection of Positrons into LEP.



Optimized Horizontal First Turn Trajectory for Synchrotron Injection of Positrons with  $\Delta P/P$  at -0.6%

Synchrotron Injection in LEP gave improved background for LEP experiments due to small orbit offsets in <u>zero dispersion straight sections</u>

### **Injection - summary**


- Several different techniques
  - Single-turn injection for hadrons
    - Boxcar stacking: transfer between machines in accelerator chain
    - Angle / position errors  $\Rightarrow$  injection oscillations
    - Optics errors  $\Rightarrow$  betatron mismatch oscillations
    - Oscillations  $\Rightarrow$  filamentation  $\Rightarrow$  emittance increase
  - Multi-turn injection for hadrons
    - Phase space painting to increase intensity
    - H- injection allows injection into same phase space area
  - Lepton injection: take advantage of damping
    - Less concerned about injection precision and matching

## Extraction

- Different extraction techniques exist, depending on requirements
  - <u>Fast extraction</u>: ≤1 turn
  - <u>Non-resonant multi-turn extraction</u>: few turns
  - <u>Resonant multi-turn extraction</u>: many thousands of turns
  - <u>Resonant low-loss multi-turn extraction</u>: few turns
- Usually higher energy than injection  $\Rightarrow$  stronger elements ( $\int B.dI$ )
  - At high energies many kicker and septum modules may be required
  - To reduce kicker and septum strength, beam can be moved near to septum by closed orbit bump

## Fast single turn extraction


Whole beam kicked into septum gap and extracted.



- Kicker deflects the entire beam into the septum in a single turn
- Septum deflects the beam entire into the transfer line
- Most efficient (lowest deflection angles required) for  $\pi/2$  phase advance between kicker and septum


#### Fast single turn extraction

- For transfer of beams between accelerators in an injector chain.
- For secondary particle production (e.g. neutrinos)
- Septum deflection may be in the other plane to the kicker deflection.
- Losses from transverse scraping or from particles in extraction gap



## Synchronisation I


- Beam from PS has to be injected into right SPS bucket wrt to SPS revolution frequency
- Set frequency
  - Before beam is transferred, e.g. from SPS to LHC, the two machines must be synchronised on a common frequency  $f_c$



Now the LHC can choose the bucket in which the first bunch will be injected
 → SPS must shift the beam to adapt to this position


# Synchronisation II

- "Coarse" rephasing
  - Shift the beam in the SPS to reach wanted LHC bucket
  - To do so the particles will run for a short period on an average radius which is different from the central orbit ("radial steering")
  - Matching of common frequency  $f_c$  with SPS revolution frequency (TDC)
- "Fine" rephasing phase matching
  - Correct the position within the bucket
  - Matching of  $f_{RF}^{LHC}$  and  $f_{RF}^{SPS}$  (phase lock loop)




## Synchronisation III

- Triggering the SPS extraction and LHC injection kickers
  - Timing event: has only 1ms resolution; serves as prepulse;
  - With  $f_c$  calculate exact timing of kicker pulse for SPS and LHC




## Multi-turn extraction


- Some filling schemes require a beam to be injected in several turns to a larger machine...
- And very commonly Fixed Target physics experiments and medical accelerators often need a quasi-continuous flux of particles...
- Multi-turn extraction...
  - Non-Resonant multi-turn ejection (few turns) for filling e.g. PS to SPS at CERN for high intensity proton beams (>2.5 10<sup>13</sup> protons)
  - Resonant extraction (ms to hours) for experiments



- Fast bumper deflects the whole beam onto the septum
- Beam extracted in a few turns, with the machine tune rotating the beam
- Intrinsically a high-loss process thin septum essential


- Example system: CERN PS to SPS Fixed-Target 'continuous transfer'.
  - Accelerate beam in PS to 14 GeV/c
  - Empty PS machine (2.1  $\mu$ s long) in 5 turns into SPS
  - Do it again
  - Fill SPS machine (23 μs long)
  - Quasi-continuous beam in SPS (2 x 1  $\mu$ s gaps)
  - Total intensity per PS extraction  $\approx 3 \times 10^{13}$  p+
  - Total intensity in SPS  $\approx 5 \times 10^{13}$  p+






# Non-resonant multi-turn extraction

- CERN PS to SPS: 5-turn continuous transfer
  - Losses impose thin (ES) septum... second septum needed
  - Still about 15 % of beam lost in PS-SPS CT
  - Difficult to get equal intensities per turn



# Resonant multi-turn extraction




- Slow bumpers move the beam near the septum
- Tune adjusted close to n<sup>th</sup> order betatron resonance
- Multipole magnets excited to define stable area in phase space, size depends on ΔQ = Q - Q<sub>r</sub>

# Resonant multi-turn extraction


- 3<sup>rd</sup> order resonances
  - Sextupole fields distort the circular normalised phase space particle trajectories.
  - Stable area defined, delimited by unstable Fixed Points.

$$R_{fp}^{1/2} \propto \Delta Q \cdot \frac{1}{k_2}$$


- Sextupoles families arranged to produce suitable phase space orientation of the stable triangle at thin electrostatic septum
- Stable area can be reduced by increasing the sextupole strength, or (easier) by approaching machine tune Q<sub>h</sub> to resonant 1/3 integer tune
- Reducing ∆Q with main machine quadrupoles can be augmented with a 'servo' quadrupole, which can modulate ∆Q in a servo loop, acting on a measurement of the spill intensity





- Particles distributed on emittance contours
- $\Delta Q$  large no phase space distortion




Dedicated sextupole magnets produce a triangular stable area in phase space
ΔQ decreasing – phase space distortion for largest amplitudes











AQ small enough that largest amplitude particles are close to the separatrices
Fixed points locations discernable at extremities of phase space triangle




•  $\Delta Q$  now small enough that largest amplitude particles are unstable


• Unstable particles follow separatrix branches as they increase in amplitude




• Stable phase area shrinks as  $\Delta Q$  gets smaller





• Separatrix position in phase space shifts as the stable area shrinks




As the stable area shrinks, the beam intensity drops since particles are being continuously extracted










• As  $\Delta Q$  approaches zero, the particles with very small amplitude are extracted.

Example – SPS slow extraction at 450 GeV/c.  $\sim 3 \times 10^{13}$  p+ extracted in a 2-4 second long spill (~200,000 turns)




Intensity vs time: ~10<sup>8</sup> p+ extracted per turn

# Second-order resonant extraction

- An extraction can also be made over a few hundred turns
- 2<sup>nd</sup> and 4<sup>th</sup> order resonances
  - Octupole fields distort the regular phase space particle trajectories.
  - Stable area defined, delimited by two unstable Fixed Points.
  - Beam tune brought across a  $2^{nd}$  order resonance (Q $\rightarrow$ 0.5)
  - Particle amplitudes quickly grow and beam is extracted in a few hundred turns.

### **Resonant extraction separatrices**




Amplitude growth for 2<sup>nd</sup> order resonance much faster than 3<sup>rd</sup> – shorter spill
Used where intense pulses are required on target – e.g. neutrino production


# Resonant low-loss multi-turn extraction

- Adiabatic capture of beam in stable "islands"
  - Use non-linear fields (sextupoles and octupoles) to create islands of stability in phase space
  - A slow (adiabatic) tune variation to cross a resonance and to drive particles into the islands (capture)
  - Variation of field strengths to separate the islands in phase space
- Several big advantages
  - Losses reduced virtually to zero (no particles at the septum)
  - Phase space matching improved with respect to existing nonresonant multi-turn extraction - all 'beamlets' have same emittance and optical parameters

# Resonant low-loss multi-turn extraction



- a. Unperturbed beam
- b. Increasing non-linear fields
- c. Beam captured in stable islands
- d. Islands separated and beam bumped across septum – extracted in 5 turns



# **Extraction - summary**

- Several different techniques:
  - Single-turn fast extraction:
    - for Boxcar stacking (transfer between machines in accelerator chain), beam abort
  - Non-resonant multi-turn extraction
    - slice beam into equal parts for transfer between machine over a few turns.
  - Resonant multi-turn extraction
    - create stable area in phase space ⇒ slowly drive particles into resonance ⇒ long spill over many thousand turns.
  - Resonant low-loss multi-turn extraction
    - create stable islands in phase space: slice off over a few turns.