



CAS

# Beam Diagnostics Lecture 2

Measuring Complex Accelerator Parameters

Uli Raich

CERN BE-BI



## Contents of lecture 2



- Some examples of measurements done with the instruments explained during the last lecture
  - Spectroscopy
  - Trajectory and Orbit measurements
  - Tune measurements
    - Traditional method
    - BBQ method
  - Transverse and longitudinal emittance measurements
  - Longitudinal phase space tomography



# Faraday Cup application

## Testing the decelerating RFQ



### **Antiproton decelerator**

- Accelerate protons to 24 GeV and eject them onto a target
- Produce antiprotons at 2 GeV
- Collect the antiprotons and cool them
- Decelerate them and cool them
- Output energy: 100 MeV



### **In order to get even lower energies:**

- Pass them through a moderator
  - High losses
  - Large energy distribution

**=> Build a decelerating RFQ**





# Waiting for Godot





# Setup for charge state measurement

# CAS




The spectrometer magnet is swept and the current passing the slit is measured



# Measuring charge state distribution

# CAS



Faraday Cup

Slit


Spectrometer magnets



# Charge state distribution measured with a Faraday Cup on a heavy ion source

CAS

Scan of Bending magnet Current with extraction voltage 20.5kV -  
11/04/03 -JCh





## Trajectory and Orbit measurements

CAS

Definitions:

Trajectory: The mean positions of the beam during 1 turn

Orbit: The mean positions over many turns for each of the BPMs


The trajectories must be controlled at injection, ejection, transition  
Closed orbits may change during acceleration or RF “gymnastics”





# LHC Button BPMs

CAS





# Trajectory Measurement at LHC injection

CAS



Knowing the optics one can deduce the orbit correction from the measurement



# The PUs

CAS






# The PS, a universal machine



## CERN Accelerator Complex



▶ p (proton)   ▶ ion   ▶ neutrons   ▶  $\bar{p}$  (antiproton)   ▶ neutrinos   ▶ electron  
 ↔↔↔ proton/antiproton conversion


LHC Large Hadron Collider   SPS Super Proton Synchrotron   PS Proton Synchrotron  
 AD Antiproton Decelerator   CTF3 Clic Test Facility  
 CNGS Cern Neutrinos to Gran Sasso   ISOLDE Isotope Separator OnLine DEvice  
 LEIR Low Energy Ion Ring   LINAC LINEar ACcelerator   n-ToF Neutrons Time Of Flight

All beams pass through the PS  
 Different particle types  
 Different beam characteristics  
 Concept of a super cycle



# The super cycle


CAS





# Beams in the PS

CAS





# Position Measurements



Red: The sum signal

Green: The difference signal

Procedure:

Produce integration gates and

Baseline signals

Baseline correct both signals


Integrate sum and difference signals

and store results in memory

Take external timing events into

account e.g. harmonic number

change,  $\gamma$ -transition etc.






# Trajectory measurements in circular machines

CAS

Needs integration gate  
Can be rather tricky  
Distance between bunches  
changes with acceleration  
Number of bunches  
may change





Raw data from pick-ups  
double batch injection





# Baseline restoration


CAS



Low pass filter the signal to get an estimate of the base line  
Add this to the original signal




# Trajectory readout electronics






# RF Gymnastics


CAS



Example of generated gate around 2<sup>nd</sup> injection



Idem, during bunch splitting






# Changing bunch frequency



- Bunch splitting or recombination
- One RF frequency is gradually decrease while the other one is increased
- Batch compression

For all these cases the gate generator must be synchronized






# Tune measurements

CAS

- When the beam is displaced (e.g. at injection or with a deliberate kick, it starts to oscillate around its nominal orbit (betatron oscillations)
- Measure the trajectory
- Fit a sine curve to it
- Follow it during one revolution






# The Sensors



# CAS



The kicker




Shoebox pick-up  
with linear cut





# Tune measurements with a single PU

CAS





Design by P. Forck



# Kicker + 1 pick-up



- Measures only non-integral part of  $Q$
- Measure a beam position at each revolution




Fourier transform of pick-up signal





# Periodic extension of the signal and Windowing

CAS





# Windowing


CAS

The Discrete Fourier transform assumes one cycle of a repetitive signal.

Blackman-Harris Window is used

Each sample is multiplied with a coefficient

Coefficients are pre-calculated and stored in a table






# Peak search algorithm

CAS

- Power value is bigger than its predecessor
- Power value is bigger than its successor
- Power value is biggest in the whole spectrum
- The power value is at least 3 times bigger than the arithmetic mean of all power bins.





# Q interpolation



Betatron signal is not a pure Harmonic but includes rev. freq Harmonics, noise ...


The windowing process is not Perfect

Coherent betatron signal is Damped in the time domain

$$V(n_\beta - 1) = a(n_\beta - 1)^2 + b(n_\beta - 1) + c$$

$$V(n_\beta) = an_\beta^2 + bn_\beta + c$$


$$V(n_\beta + 1) = a(n_\beta + 1)^2 + b(n_\beta + 1) + c$$





# Q-Measurement Results


# CAS





# Direct Diode Detection Base Band Q measurement

CAS



Diode Detectors convert spikes to saw-tooth waveform

Signal is connected to differential amplifier to cut out DC level

Filter eliminates most of the revolution frequency content


Output amplifier brings the signal level to amplitudes suitable for long distance transmission




# BBQ Results from CERN SPS

CAS

## Results from Sampling





## After Fourier Transform






# Tune feedback at the LHC







A beam is made of many many particles, each one of these particles is moving with a given velocity. Most of the velocity vector of a single particle is parallel to the direction of the beam as a whole ( $s$ ). There is however a smaller component of the particles velocity which is perpendicular to it ( $x$  or  $y$ ).


$$\vec{v}_{particle} = v_s \hat{u}_s + v_x \hat{u}_x + v_y \hat{u}_y$$



# Emittance measurements

CAS

- If for each beam particle we plot its position and its transverse angle we get a particle distribution whose boundary is an usually ellipse.
- The projection onto the  $x$  axis is the beam size






# The slit method

CAS

- If we place a slit into the beam we cut out a small vertical slice of phase space
- Converting the angles into position through a drift space allows to reconstruct the angular distribution at the position defined by the slit







# Transforming angular distribution to profile

CAS


- When moving through a **drift space** the angles don't change (**horizontal move** in phase space)
- When moving through a **quadrupole** the position does not change but the angle does (**vertical move** in phase space)



Influence of a drift space



Influence of a quadrupole







# The Slit Method

# CAS


3-dim plot:





# Phase Space Scanner

CAS





## Moving slit emittance measurement







- Position resolution given by slit size and displacement
- Angle resolution depends on resolution of profile measurement device and drift distance
- High position resolution  $\rightarrow$  many slit positions  $\rightarrow$  slow
- Shot to shot differences result in measurement errors



# Single pulse emittance measurement

# CAS








# Transformation in Phase Space


CAS





# Result of single pulse emittance measurement

CAS



FREEZE

CANCEL BEAM

Waiting for new acquisition...



# Single Shot Emittance Measurement

CAS


- Advantage:
  - Full scan takes 20  $\mu$ s
  - Shot by shot comparison possible
- Disadvantage:
  - Very costly
  - Needs dedicated measurement line
  - Needs a fast sampling ADC + memory for each wire
- Cheaper alternative:
  - Multi-slit measurement



# Longitudinal Phase Space Transformation

CAS


- Spectrometer produces image of slit on second slit
- second slit selects energy slice
- first kicker sweep phase space over all energies
- buncher rotates energy slice in phase space
- at second spectrometer the phase distribution is transformed into an energy distribution analyzed by the second spectrometer
- second kicker corrects for first kick





# Transverse Emittance measurement


CAS





# Photos of the line

# CAS





# Computed Tomography (CT)

CAS

Principle of Tomography:


- Take many 2-dimensional Images at different angles
- Reconstruct a 3-dimensional picture using mathematical techniques (Algebraic Reconstruction Technique, ART)






# The reconstruction


CAS




Produce many projections of the object to be reconstructed



Back project and overlay the "projection rays"



Project the back-projected object and calculate the difference





Iteratively back-project the differences to reconstruct the original object





# Some CT results

CAS







# Computed Tomography and Accelerators

CAS


RF voltage



Restoring force for non-synchronous particle



Longitudinal phase space





Projection onto  $\Phi$  axis corresponds to bunch profile



# Reconstructed Longitudinal Phase Space

CAS





# Bunch Splitting

CAS

